



*Application Instructions for*  
**Colour Print Glitter**

**Use on Thermal and Ink Jet  
 Eco/Solvent printers**

Recommended Fabrics:

- 100% Cotton
- 100% Polyester
- Poly/cotton blends

Use Colour Print Mask for excellent results.

Accessories Required: Release paper, Silicon Paper or Teflon sheet, Colour Print Mask

**DESCRIPTION:** Glitter material specifically formulated for thermo-resin, inkjet solvent and eco-solvent based inks. Suitable for normal textiles (**WITHOUT SILICON TREATMENT**) it is very opaque Even on dark fabrics.

**TIPS:** Let print dry for at least 12 hours before rolling, overlaying or heat applying to garments.

1. Print and cut the material
2. **Let print dry for at least 12 hours**
3. Remove image from backing sheet.
4. Place image on garment face up cover with Silicon sheet or Teflon sheet and heat apply.

5. Heat Apply –  
 Temperature: 160°C  
 Time: 15 seconds  
 Pressure: Low/Medium. On Target NEW Pressure sensing presses set between 1-5  
 For T-Shirts only. (Reduce for thicker garment)
6. Remove protective covering when **COLD**.

**Washing Instructions:**

- Machine-wash inside out at 40°C using a mild detergent.
- Do not bleach.
- Iron in reverse – do not iron directly on to GLITTER COLOUR PRINT.

*All technical information and recommendations are based on tests we believe to be reliable. However, we cannot guarantee performance under conditions not under manufacturer's control. Before using, please determine suitability of product for its intended use. I.e, do your own wash test, The type and amount of water repellent treatments varies significantly on different nylons. This factor will determine how well "Advantage" adheres. Therefore we cannot guarantee adhesion to all nylon fabrics. Warranty of product is to replace product only and not the item this has been applied to.*

*Using transfer paper may invalidate printer warranty please check with printer manufacturer or supplier.*